


03023

AIRPORT DIAGRAM

SPRINGFIELD/CAPITAL (SPI)
SPRINGFIELD, ILLINOIS

AL-518 (FAA)



AIRPORT DIAGRAM

03023

SPRINGFIELD, ILLINOIS
SPRINGFIELD/CAPITAL (SPI)